

Setting up your 1PHONE ATA device without a Router is as easy as A, B, C!

The 1Phone product is a Voice over Internet Protocol (VoIP) product that delivers advanced telephone services without the need of a traditional phone line. It is delivered via an Analog Telephone Adapter (ATA) device. There are five (5) connections on the device: four (4) on the rear of the device and one (1) on the side.

DC 5v - This is where the power plug connects to the device. The device comes with a 5vDC power adapter.

WAN - (Wide Area Network) - This is a RJ-45 CAT5 network cable connection. This is where you will connect the incoming Internet cable. This cable may come directly from a cable modem or a router.

LAN - (Local Area Network) - This is a RJ-45 CAT5 network cable connection. This is where you can connect a cable to a computer. This is a 10bps connection.

Phone - This is where you will connect your phone line to your phone.

Line - If you have existing phone service, you could connect a phone line into this connection. If power or your internet fails at home (or office) the ATA will automatically switch to using this land line. If you want to use this line to make and outbound call during normal operation, you would need to dial *00 first to go around the 1PHONE device.

To acquire the 1PHONE ATA's IP Address - Pick up the hand set and press the * key four times fast. Once you hear the option to enter a menu, you will want to press 02. The IVR system will state the IP Address of the 1PHONE ATA. It will do it in four sets of 3 digit numbers divided by a dot annotation. Example:192.168.002.003.

The 1PHONE ATA device can be connected two ways to your network. This can be done with a router or without a router. The following two pages will explain the simple set up method for use with a router or without a router.

Many homes only have a single computer and the need for a router is not required. Thus your Internet Service Provider may have provided you with a Cable or DSL modem. A modem can only connect a single device to the Internet. If you have this type of connection you will have a network cable running from your modem directly to the back of your computer.

- A. To install the 1PHONE ATA device you will need to unplug the network cable from your computer and plug it into the WAN port of the 1PHONE ATA device.
- B. Next, you will take the supplied network cable and plug it into the LAN port on the 1PHONE device and the other end of the cable into your computer. In essence, the 1PHONE ATA device sits between your modem and your computer.
- C. Last, you will connect your phone cable to the phone port; and finally you will connect the power adapter into the wall as well as into the 1PHONE ATA device.

Once all the cables are connected, you will need to reset the power on your modem by removing and reinserting the power cable. once the modem has initialized and is back on-line, you will be able to surf the Internet and use your 1PHONE service.

The 1PHONE ATA device may take up to 10 minutes to synchronize. If you have questions about installing the 1PHONE ATA device, please call 1-800-607-5000 to speak to a 1PHONE Customer Care Representative.

